

# FRAUNHOFER INSTITUTE FOR INTEGRATED SYSTEMS AND DEVICE TECHNOLOGY



1 Lock-In Thermography in action

# LOCK-IN THERMOGRAPHY

Non-destructive localization of electric active defects

# Description of lock-in thermography analysis

- Detecting of failed power electronic devices such as IGBT, MosFETs, diodes and resistors
- Analysis of short circuits, ESD defects, oxide damages, edge termination defects, avalanche brake down, whiskers and electrical conductive contamination
- High sensitivity for hot spot detection with a heat dissipation in the  $\mu W$  range
- 2D/3D defect localization for further destructive analysis to identify the failure mechanism

## **Special features**

- Measurement voltage from mV up to 10 kV
- Decapsulation of mold compounds as well as silicone gels
- Chemical removal of chip topside metallization and contacts for instance bond wires and ribbons out of different materials
- Follow up investigations such as cross sections, scanning electron microscopy, micro sections with focused ion beam
- Interpretation of test results and failure mechanisms
- Consultancy on the different investigated failure modes for instance chip damage due to improper bond wire process parameters

Fraunhofer Institute for Integrated Systems and Device Technology IISB

Landgrabenstraße 94 90443 Nürnberg Germany

#### Contact:

Adam Tokarski Phone: +49 911 235 68 157 Fax: +49 911 235 68 12 adam.tokarski@iisb.fraunhofer.de

www.iisb.fraunhofer.de





### **Analysis principle**

- The device under test is pulsed with the rectangular voltage by arbitrary lock-In frequency (typical: 1 to 25 Hz)
- Electrical defect dissipate thermal power
- Thermal power heats up the surface
- Measurement of infrared signal with infrared camera
- Acquisition of amplitude image as well as resulting time dependent step response (phase image)


#### **Advantages**

- Differential measurement principle
- Best suited for different emission coefficients of the device surface materials
- No influence of the ambient (temperature, reflections)
- Three different zoom lenses to investigate structures from complete power module to single IGBT cells

## **Application example**

- After fabrication, a power module failed the final electrical quality test (e.g. gate-emitter leakage current)
- Lock-in thermography helps to detect which semiconductor is responsible for the leakage current and determinds the exact position of the defect on the device
- Next step consists of removing bond wires and aluminium-metalization of the semiconductor followed by a second lock-in thermography analysis to get the micro scale location of the defect
- An additional investigation can be a focused ion beam investigation with scanning electron microscopy to detect the cause of failure (e.g. damaged gate structure)





Demolded device


Topography






Cross section

Focused ion beam



Power modul







2 Optical Microscopy of IGBT
3 Lock-In Thermography Amplitude of IGBT
4 Lock-In Thermography Phase of IGBT

Lock-in detail